



ENCORE
PROFESSIONAL LIGHTING

AuraPar™ 7HEX IP

3CH Mode

CHANNEL	VALUE	FUNCTION	PRIORITY	REMARKS
1	000-255	RGB color mixing		tonal
2	000-255	UV dimming 0-100%		
3	000-255	General dimming 0-100%		purity

6CH Mode

CHANNEL	VALUE	FUNCTION	PRIORITY	REMARKS
1	000-255	Red dimming 0-100%		
2	000-255	Green dimming 0-100%		
3	000-255	Blue dimming 0-100%		
4	000-255	Amber dimming 0-100%		
5	000-255	White dimming 0-100%		
6	000-255	UV dimming 0-100%		

8CH Mode

CHANNEL	VALUE	FUNCTION	PRIORITY	REMARKS
1	000-255	General dimming 0-100%		
2	000-255	Red dimming 0-100%		
3	000-255	Green dimming 0-100%		
4	000-255	Blue dimming 0-100%		
5	000-255	Amber dimming 0-100%		
6	000-255	White dimming 0-100%		
7	000-255	UV dimming 0-100%		
8	000-255	Strobe dimming (fast - slow)		



ENCORE
PROFESSIONAL LIGHTING

FlyPar™ 4HEX

10CH Mode

CHANNEL	VALUE	FUNCTION	PRIORITY	REMARKS
1	000-255	General dimming 0-100%	1	
2	000-255	Red dimming 0-100%		
3	000-255	Green dimming 0-100%		
4	000-255	Blue dimming 0-100%		
5	000-255	Amber dimming 0-100%		
6	000-255	White dimming 0-100%		
7	000-255	UV dimming 0-100%		
8	000-014	Not used	2	
	015-255	Strobe (fast - slow)		
9	000-031	Not used	3	Must use channels 1-6 to get light. Channel 9 is speed adjustment.
	032-063	Dark - bright		
	064-095	Bright - dark		
	096-127	Dark -bright - dark		
	128-159	Fade		
	160-191	Dark -bright - dark (auto run)		
	192-223	Color flash change		
224-255	Sound activated			
10	000-255	Speed adjustment		Slow - fast



ENCORE
PROFESSIONAL LIGHTING

FlyPar™ 4HEX

11CH Mode

CHANNEL	VALUE	FUNCTION	PRIORITY	REMARKS
1	000-255	General dimming 0-100%	1	
2	000-255	Red dimming 0-100%		
3	000-255	Green dimming 0-100%		
4	000-255	Blue dimming 0-100%		
5	000-255	Amber dimming 0-100%		
6	000-255	White dimming 0-100%		
7	000-255	UV dimming 0-100%		
8	000-014	Dimming	2	
	015-255	Strobe (fast - slow)		
9	000-031	Not used	3	Must use channels 1-6 to get light. Channel 9 is speed adjustment.
	032-063	Dark - bright		
	064-095	Bright - dark		
	096-127	Dark -bright - dark		
	128-159	Fade		
	160-191	Dark -bright - dark (auto run)		
	192-223	Color flash change		
224-255	Sound activated			
10	000-255	Speed adjustment		Slow - fast
11	000-005	Uses the "nodE" setting		Similar to the "nodE" setting, but with variable speed control. DIMMER0 has the fastest range, DIMMER4 the slowest. Dependent on use of channels 1-7.
	006-055	DIMMING 0		
	056-105	DIMMING 1		
	106-155	DIMMING 2		
	155-205	DIMMING 3		
	205-255	DIMMING 4		