



ENCORE
PROFESSIONAL LIGHTING

AuraBeam™ 230

Mode/Channel		Function	Values	Description
Standard	Vector			
1	1	Pan	0-255	PAN Movement
2	2	Pan-fine	0-255	Fine control of Pan movement
3	3	Tilt	0-255	Tilt Movement
4	4	Tile-fine	0-255	Fine control of Tilt movement
5	5	Color wheel	0-4	Open / white
			5-9	White + Color 1
			10-14	Color 1
			15-19	Color 1 + Color 2
			20-24	Color 2
			25-29	Color 2 + Color 3
			30-34	Color 3
			35-39	Color 3 + Color 4
			40-44	Color 4
			45-49	Color 4 + Color 5
			50-54	Color 5
			55-59	Color 5 + Color 6
			60-64	Color 6
			65-69	Color 6 + Color 7
			70-74	Color 7
			75-79	Color 7 + Color 8
			80-84	Color 8
			85-89	Color 8 + Color 9
			90-94	Color 9
			95-99	Color 9 + Color 10
100-104	Color 10			
105-109	Color 10 + Color 11			
110-114	Color 11			
115-127	Color 11 + White			
128-189	Forwards rainbow effect from fast to slow			
190-193	Color rotation stop			
194-255	Backwards rainbow effect from slow to fast			
6	6	Gobo wheel 1	0-4	Open
			5-9	Gobo 1
			10-14	Gobo 2
			15-19	Gobo 3
			20-24	Gobo 4
			25-29	Gobo 5
			30-34	Gobo 6



ENCORE

PROFESSIONAL LIGHTING

			35-39	Gobo 7
			40-44	Gobo 8
			45-49	Gobo 9
			50-54	Gobo 10
			55-59	Gobo 11
			60-64	Gobo 12
			65-69	Gobo 13
			70-74	Gobo 14
			75-79	Gobo 15
			80-84	Gobo 16
			85-92	Gobo 1 shake slow to fast
			93-100	Gobo 2 shake slow to fast
			101-107	Gobo 3 shake slow to fast
			108-116	Gobo 4 shake slow to fast
			117-124	Gobo 5 shake slow to fast
			125-132	Gobo 6 shake slow to fast
			133-140	Gobo 7 shake slow to fast
			141-148	Gobo 8 shake slow to fast
			149-156	Gobo 9 shake slow to fast
			157-164	Gobo 10 shake slow to fast
			165-172	Gobo 11 shake slow to fast
			173-180	Gobo 12 shake slow to fast
			181-188	Gobo 13 shake slow to fast
			189-196	Gobo 14 shake slow to fast
			197-204	Gobo 15 shake slow to fast
			205-212	Gobo 16 shake slow to fast
			213-255	Rot. gobo wheel cont. rotation slow to fast
7	7	Shutter	0-31	Shutter closed
			32-63	Shutter open
			64-95	Strobe effect slow to fast
			96-127	Shutter open
			128-143	Opening pulse in sequences slow to fast
			144-159	Closing pulse in sequences fast to slow
			160-191	Shutter open
			192-223	Random strobe effect slow to fast
			224-255	Shutter open
8	8	Dimmer	0-255	Dimmer 0%...100%
9	9	Focus	0-255	In(near) to Out(far)
10	10	Rrotating prism	0-5	Prism swing out(hole)
			6-127	Prism swing in
			128-189	Prism Forwards rotation from fast to slow
			190-193	Prism rotation stop
			194-255	Prism Backwards rotation from slow to fast



ENCORE
PROFESSIONAL LIGHTING

11	11	Frost	0-199	Frost swing out
			200-255	Frost swing in
12	12	Speed pan/tile	0-225	max to min speed
			226-235	blackout by movement
			236-245	blackout by all wheel changing
			246-255	No function
13	13	Special function	0-19	No function
			20-29	No function
			30-39	No function
			40-59	Lamp on
			60-79	Lamp switch off
			80-84	Total Reset
			85-87	Pan/Tilt Reset
			88-90	Color Reset
			91-93	Gobo Reset
			94-96	Strobe Reset
			97-99	The Others Reset
			100-119	Internal program 1
			120-139	Internal program 2
			140-159	Internal program 3
			160-179	Internal program 4
			180-199	Internal program 5
200-219	Internal program 6			
220-239	Internal program 7			
240-255	Internal program 8			
	14	Color Time	0-255	max to min speed
	15	Gobo Time	0-255	max to min speed